


84" HIGH CABINETS - Also available in 86", 88" and 94" height

84" HIGH CABINETS - 24" DEEP (OPTIONAL 12" DEEP)


UTILITY/BROOMER

2 Door



UBI284 L/R
UBI584 L/R
UB1884 L/R
UB2184 L/R


4 Door



UB2484
UB2784
UB3084
UB3384
UB3684


PANTRY CABINET W/SHELVES

2 Door



PC1284 L/R
PC1584 L/R
PC1884 L/R
PC2184 L/R


4 Door



PC2484
PC2784
PC3084
PC3384
PC3684

COMBINATION PANTRY/BROOMER


4 Door



CPB3084
CPB3684

DOUBLE OVEN CABINET


2 Door/1 Dw.



DOC2784
DOC3084
DOC3384

OVEN/DISHWASHER CABINET


2 Door



ODW2784
ODW3084
ODW3384

OVEN OR MICROWAVE CABINET


4 Door



OC2784 MWC2484
OC3084 MWC2784
OC3384 MWC3084

OVEN CABINET W/DRAWER


2 Door/2Dw.



OCD2784
OCD3084
OCD3384

OVEN/MICROWAVE CABINET


2 Door/1 Dw.



OMW2784
OMW3084
OMW3384

OVEN CABINET W/POT AND PAN DRAWER


2 Door/3 Dw.



OCBDP2784
OCBDP3084
OCBDP3384

REFRIGERATION CABINET

2 Door



RC3084
RC3384
RC3684
RC3984

(OVEN OPENING IS 26 1/2" HIGH AND 21", 24", 27" WIDE.)

(MICROWAVE OPENING IS 16" HIGH AND 21", 24", 27" WIDE.)

RC OPENINGS ARE 3" LESS THAN CABINET WIDTH. OPENING IS 69" HIGH)